

Address		Register parameters			Description	Values
Dec	Hex	Type	Access	Format		
Coil registers						
1	0x0001	Coil	RW	Bool	Air conditioner status	0 – Disabled 1 – Enabled
2	0x0002	Coil	RW	Bool	Screen backlight	0 – Disabled 1 – Enabled
3	0x0003	Coil	RW	Bool	Screen brightness	0 - High 1 – Low
4	0x0004	Coil	RW	Bool	Quiet mode	0 – Disabled 1 – Enabled
6	0x0006	Coil	RW	Bool	Eco mode	0 – Disabled 1 – Enabled
7	0x0007	Coil	RW	Bool	Turbo mode	0 – Disabled 1 – Enabled
20	0x0014	Coil	R	Bool	Air conditioner connected	0 - No 1 – Yes
100	0x0064	Coil	RW	Bool	Use external temperature sensor	0 - No 1 – Yes
Holding registers						
1	0x0001	Holding	RW	UInt16	Operating mode	1 – Heating 2 – Cooling 3 – Automatic 4 – Dehumidification 5 – Ventilation
2	0x0002	Holding	RW	UInt16	Status and mode This register helps integrate with systems where switching off is controlled by the same register as the mode.	0 – Off 1 – Heating 2 – Cooling 3 – Automatic 4 – Dehumidification 5 – Ventilation

3	0x0003	Holding	RW	SInt16	<p align="center">Indoor air temperature, °C</p> <p>By default, this register stores the air temperature measured by the air conditioner's built-in sensor. When a temperature value from an external sensor is written to this register, the value will be returned with the correction shown in register 20.</p>	<p align="center">-32768...32768</p> <p>To obtain the temperature, multiply the value by 0.01. For example, 2560 equals 25.6 °C.</p>
4	0x0004	Holding	R	SInt16	<p align="center">Outdoor air temperature, °C</p>	<p align="center">-32768...32768</p> <p>To obtain the temperature, multiply the value by 0.01. For example, 2560 equals 25.6 °C.</p>
5	0x0005	Holding	RW	SInt16	<p align="center">Target temperature, °C</p> <p>The temperature is set with an accuracy of 0.5°C</p>	<p align="center">1600...3200</p> <p>To get the temperature, multiply the value by 0.01. For example, 2500 is 25.0 °C.</p>
6	0x0006	Holding	R	UInt16	<p align="center">Thermostat status</p>	<p align="center">0 – Idle 1 – Heating 2 – Cooling</p>
7	0x0007	Holding	RW	UInt16	<p align="center">Fan speed</p>	<p align="center">0 - Auto 1 - 1 speed 2 - 2 speed 3 - 3 speed 4 - 4 speed 5 - 5 speed</p>
8	0x0008	Holding	RW	UInt16	<p align="center">Extended fan speed</p> <p>This register helps integrate with systems where only one register can be used to control the fan speed. Enabling Quiet and Turbo modes does not change the fan speed state (shown on the air conditioner display and in Holding Register No. 7).</p>	<p align="center">0 – Auto 1 – Quiet mode 2 – First speed 3 – Second speed 4 – Third speed 5 – Fourth speed 6 – Fifth speed 7 – Turbo mode</p>

9	0x0009	Holding	RW	UInt16	Horizontal louvers	0 - Stop 1 - Swing
10	0x000A	Holding	RW	UInt16	Vertical louvers	0 - Stop 1 - Swing
11	0x000B	Holding	RW	UInt16	Airflow direction This register helps integrate with systems where only one register can be used to control airflow direction.	0 - Stopped 1 - Horizontal and vertical swing 2 - Horizontal louver swing 3 - Vertical louver swing
15	0x000F	Holding	RW	UInt16	Operating mode (for Loxone)	1 - Automatic 2 - Heating 3 - Cooling 4 - Dehumidification 5 - Ventilation -32768...32768
20	0x0014	Holding	RW	Sint16	Temperature correction	To obtain the temperature, multiply the value by 0.01. For example, 100 equals 1.00 °C
31	0x001F	Holding	R	Sint16	Target fan speed (RPM)	0...200
32	0x0020	Holding	R	Sint16	Current fan speed (RPM)	0...200
Holding registers (service)						
110	0x006E	Holding	RW	Sint16	Modbus speed	
111	0x006F	Holding	RW	UInt16	RS-485 port parity setting	
112	0x0070	Holding	RW	UInt16	RS-485 port stop bits	1, 2
128	0x0080	Holding	RW	UInt16	Modbus device address	1...247
200 - 219	0x00C8 - 0x00DB	Holding	R	String	Hardware version of the device	DK-1-MB-B
250 - 265	0x00FA- 0x0109	Holding	R	String	Device software version	0.4.7 and later
270 - 271	0x010E - 0x010F	Holding	R	UInt32	Device serial number	
400 - 420	0x0190 - 0x01A4	Holding	R	String	Air conditioner communication protocol version	2.0.13 - current